

# GEM-FIX

## MODULES / SUBJECTS

### Tech

 Identification data

 Recalls

 Maintenance

 Repair manuals

 Adjustment data

 Repair times

 Lubricants and fluids

 Technical drawings

### Tech

### Electronics

 VESA™ MK II (Guided diagnostics)

 Comfort wiring diagrams

 Fuses and relays


### Tech + Electronics

### Smart

 Technical Service Bulletins (SmartFIX™)

 Recalls

 Verified fixes & tips (SmartCASE™)





## MODULES / SUBJECTS / FEATURES

### Tech

SUBJECTS	FEATURES
<b>Identification data</b>	<ul style="list-style-type: none"> <li>• VIN and identification plate locations</li> <li>• VIN decoder</li> <li>• Equipment codes</li> </ul>
<b>Maintenance</b>	<ul style="list-style-type: none"> <li>• Maintenance schedules (OEM-based)</li> <li>• Printable work sheets</li> <li>• Smart links to relevant data</li> <li>• Links to generic parts</li> <li>• Follow-up tasks</li> <li>• Additional tasks</li> <li>• Service times</li> <li>• Service indicator reset</li> <li>• Procedures for Electronic and Hybrid vehicles</li> <li>• Tyre pressure monitoring system</li> <li>• Overview of all important wear part intervals</li> </ul>

### Tech

SUBJECTS	FEATURES
<b>Repair times</b>	<ul style="list-style-type: none"> <li>• Overlap technology</li> <li>• Specific and generic times</li> <li>• Follow-up work</li> <li>• Links to generic parts</li> <li>• OE Reference codes</li> </ul>
<b>Technical drawings</b>	<ul style="list-style-type: none"> <li>• Torque settings</li> <li>• Links to generic parts</li> </ul>

### Electronics

SUBJECTS	FEATURES
<b>Fuses and relays</b>	<ul style="list-style-type: none"> <li>• Fuse and relay box locations</li> <li>• Fuse and relay overview</li> </ul>

<b>Lubricants and fluids</b>	<ul style="list-style-type: none"> <li>• Qualities and viscosities</li> <li>• Gearbox plug locations</li> </ul>
<b>Recalls</b>	<ul style="list-style-type: none"> <li>• Safety related recall actions issued by OEM</li> </ul>
<b>Repair manuals</b>	<ul style="list-style-type: none"> <li>• Timing belt; removal/installation</li> <li>• Timing chain; removal/installation</li> <li>• Ancillary drive belt; removal/installation</li> <li>• Clutch: removal/installation</li> <li>• Manual transmission; removal/installation</li> <li>• Cooling system; drain/refill</li> <li>• Engine assembly; removal/installation</li> <li>• Battery: procedures for disconnection/reconnection</li> <li>• (Semi-) automatic transmission fluid level check and drain / refill</li> <li>• Turbocharger: removal/installation</li> <li>• Self-levelling suspension: jacking up mode</li> <li>• Electronic parking brake (EPB) procedures</li> <li>• ... and many more!</li> </ul>

<b>Comfort wiring diagrams</b>	<ul style="list-style-type: none"> <li>• Wiring diagrams covering e.g. central locking, power windows, airbags, exterior lights, starting/charging, instrument cluster, parking assistance, horns and wash/wipe systems</li> <li>• Pan and zoom functionality</li> <li>• Link to component locations</li> </ul>
--------------------------------	---

### Smart

SUBJECTS	FEATURES
<b>Technical Service Bulletins (SmartFIX™)</b>	<ul style="list-style-type: none"> <li>• Technical Service Bulletins</li> <li>• Link to fault codes and related cases</li> </ul>
<b>Verified fixes &amp; tips (SmartCASE™)</b>	<ul style="list-style-type: none"> <li>• Verified fixes and tips</li> <li>• Link to fault codes and related cases</li> </ul>
<b>Recalls</b>	<ul style="list-style-type: none"> <li>• Safety related recall actions issued by OEM</li> </ul>